

Версия ПО□



%%SpecCode39

Возврат к заводским настройкам:



%%SpecCode93

Установить пользовательские настройки:



%%SpecCode92

Настройки языка

American English (Chinese):



%%SpecCode40

German:



%%SpecCode41

French:



%%SpecCode42

Spanish:



%%SpecCode43

Italian:



%%SpecCode44

Japanese:



%%SpecCode45

Универсальный язык:



%%SpecCode46

Belgian French:



%%SpecCode47

Portuguese:



%%SpecCode48

British English:



%%SpecCode49

German IOS клавиатура:



%%SpecCode48

Brazilian

Portuguese



%%SpecCode48

Russian:



%%SpecCode4C

Czech:



%%SpecCode4D

Italian 142:



%%SpecCode4E

Turkey Q:



%%SpecCode4F

Turkey F:



%%SpecCode50

Sweden / Finland



Mexican Spanish:



Danish:



Norwegian (Written Norwegian):



Croatian:



Swiss German:



Swiss French:



Dutch:



Hungarian:



Polish:



Canadian French:



Argentina (Latin):



Slovak:



Войти GBK code:



Войти UTF encoding:



Привязка приёмника



Настройки звука:

Тихо



Средне



Громко

























